

User manual Cutting guide compact (A-0420)

The Cutting guide compact is a manual guide for use with SafetyTools cutting solutions. The guide uses a magnet to lock a guide rail to the surface. It will stabilize the cutting machine and make the cutting easier. It will also reduce the cutting time and prolong the lifespan of the cutting disc.




The standard cutting guide is 51cm long and has a cutting distance of 42cm. On request, it can be custom made to fit different lengths.



v 1.0

Setting up the cutting guide compact:

To setup the cutting guide compact, insert the A-0105 (Fuju angle grinder) into the “machine locking” and use an Allan key to fasten the two fastening screws. Make sure the machine is fastened properly.



Make sure the cutting disc is attached with a 90deg angle to the surface.

Using the cutting guide compact:

Use the magnet to fasten the guide to the surface you are cutting. Makes sure it is properly attached and secured to prevent it from dropping. Move the machine back and forward along the rail to get the most efficient cutting.

Please see the user manual for operating the cutting machine and the water control box before using the machine. Make sure to operate it while having a stable working position and make sure that no fingers or limbs can get caught in-between any of the moving parts.

For videos of the arm in use please visit: <http://www.safetytools.no/product/a-0420-cutting-guide-compact/>